CHARGE YOUR CAR



Choose a method




Scan QR Code using your phone's camera

➤ App-Less. No sign up required



Scan QR Code using the VoltShare app QR scanner





➤ Live charging status

*Important: you will need to have stable internet connection before starting a session. Please note that the charging price is set by the venue owner. For any technical support, please contact VoltShare below

Start Charging*



Plug in your car & lock your doors



Scan the QR code using your preferred method



Ensure the charging point is Connected. If not see FAQ's



Add a valid payment card & click on start charging



Unplug the cable from your car to end the session



See FAQ's or contact VoltShare for any assistance



FAQ & SUPPORT



0808 303 0629



support@voltshare.co.uk

GET VOLTSHARE

ACCEPTED PAYMENTS





...and more





*Need Help? Our helpline is monitored 24/7

➤ Not showing Connected or Session failed, stopped early Switch off car and lock doors. Reset connection status by unplugging the charging lead, waiting 10s & plugging back in. Refresh app page / re-scan QR code to get updated connection status.

➤ Charging point status showing Offline or Unavailable

Regularly refresh the app page (press back button) or web page for updated status as this may be due to intermittent internet loss.

> After your session has finished

Please show consideration for the venue and others by keeping all cables tidy and fully secured for the next driver.